




# DOMINO




## D 415

660x456x690






	3 x1 	4 x1 	6 x12 	22 x24 	23 x24 	29 x8 	
60 x6 	61 x22 	68 x16 	71 x6 	73 x16 	80+81 x4 	87 x6 	92 x50 
15mm	DU 2	12mm	7x50mm	5x40mm	400mm		1,4x20mm









Pro snazší otevírání zásuvek vyjměte gumový doraz pojezdu.







Přední hrana výsuvu musí být zároveň s přední hranou C2



D 415

3/3



15

